

## Resistance List Munkadur® Classic

Agent	Concentration	Assessment	Period	Remarks
<b>Acids:</b>				
phosphoric acid	5 %	+	9 months	Lightly discolouration
nitric acid	5 %	-	1 month	Discolouration, blistering
hydrochloric acid	5 %	±	1 month	Lightly discoloured
sulphuric acid	5 %	±	1,5 months	Darker discolouration
sulphureous acid (2 g/l)	0,2 %	++	12 month	
formic acid	98 %	-		
formic acid	2 %	++	1 month	
acetic acid	10 %	++	1 month	
lactic acid	90 %	±		
peracetic acid 10 %ig	0,5 %	++	1 month	
peracetic acid 10 %ig	1 %	±	1 month	Surface plainly matted
acidity of wine	10 %	+	7 months	Brightly discoloured
citric acid	10 %	++	7 months	
<b>Caustics:</b>				
ammonia	25 %	-	9 months	Blistering
potash solution	35 %	-	9 months	
caustic soda	35 %	+	9 months	Minimum discolouration
caustic soda	50 %	++	14 months	
<b>Salines:</b>				
aluminium sulphate	25 %	++	7 months	
ammonium chloride	15 %	++	7 months	
ammonium-nitrate urea solvent	100 %	++	12 months	
ammonium sulphate	10 %	++	8 months	
calcium hydrate (lime paste)		++	9 months	
ferrichlorid	10 %	0	8 months	Surface black coloured
ferrous sulphate	10 %	++	7 months	
potassium carbonate	20 %	++	7 months	
potassium nitrate	10 %	++	7 months	
potassium sulphate	5 %	++	8 months	
magnesium chloride	15 %	++	9 months	
sodium bicarbonate	15 %	++	7 months	
sodium chloride	15 %	++	7 months	
sodium acid sulphate	10 %	0	7 months	Surface darker discoloured
sodium phosphate	10 %	++	7 months	
<b>Other media:</b>				
hydrogen peroxide	3 %	++	1 month	
	5 %	+	1 month	

YOUR PARTNER FROM CONCEPT TO COMPLETION

---

**Resistance List Munkadur® Classic**


---

<b>Agent</b>	<b>Concentration</b>	<b>Assessment</b>	<b>Agent</b>	<b>Assessment</b>
Organic media:			Food and luxury articles:	
acetaldehyde	100 %	–	beer	++
acetone	100 %	–	fruit-juices	++
petrol	100 %	++	inseed oil	++
benzol		++	milk	++
diesel oil		++	mineral water	++
acetic ether		–	sour milk	++
animal fat	100 %	++	champagne	++
vegetable fat	100 %	++	salad oil	++
formaldehyde	2 %	++	tomato juice	++
glykol		++	potable-water	++
glyzerine		++	wine	++
heating fuel oil		++	vermouth	++
methanol		–	lemon juice	++
dichloromethane		–	sugar solution	++
methyl ethyl ketone		–		
methyl isobutyl ketone		–		
tetrachloroethylene		++		
petroleum		++		
turbine fuel		++		

---

Test temperature: 20°C +/- 2°C

**LEGEND**

++	:	stable
+	:	possible minimum discolouration
–	:	instabel
±	:	the surface is plainly matted
0	:	discolouration

date of revision: 07/99

YOUR PARTNER FROM CONCEPT TO COMPLETION